CAPTUR Range

Remote Control Range for DSLR's

Prepare to be amazed

Photography news
2015
A W A R D S
[BEST STUDIO/LIGHTING ACCESSORY]

+X
PLUS X AWARD®
2016 achieved for:
Innovation
Ease of Use
Functionality

hähnel **CAPTUR**
Module - IR
High
Low

hähnel **CAPTUR**
Module - Pro
DELAY LONG INTVL1 INTVL2 N
88:88'88"
SOUND IR LIGHT LASER AUX
Lock   Start/Stop
SET

hähnel **CAPTUR**
Module - Timer
DELAY LONG INTVL1 INTVL2 N
88:88'88"
[888]
Lock   Start/Stop
SET

hähnel **CAPTUR**
Receiver

hähnel **CAPTUR**
Transmitter

The Captur range will take your photography skills on to the next level and open your eyes to a whole new world of creativity.

CAPTUR

Remote Control & Flash Trigger

For Canon:
1000 710.0

For Nikon:
1000 710.1

For Sony:
1000 710.2

For Oly/Pana:
1000 710.3

For Fuji:
1000 710.4

Wireless Remote control up to 100m range

Combining two products in one - a wireless remote shutter release and a remote flash trigger

WIRELESS
UP TO
100m
2.4GHz

Receiver

Transmitter

- Wireless Remote Shutter Release for DSLR cameras
- Wireless Remote Control for DSLR flashgun
- Interchangeable Camera connector cables included per brand
- Autofocus & Shutter Release with Continuous shooting & Bulb Mode
- Additional receivers available to trigger multiple flashguns or cameras
- Additional Captur accessories available to capture Time-lapse Photography, High Speed Photography and Motion & Wildlife Photography
- Powered by AA batteries
- DCM - Digital Channel Matching

Wireless Flash Remote control up to 100m range

Transmitter

Receiver

Receiver

Extra Receivers

For Canon:
1000 710.5

For Nikon:
1000 710.6

For Sony:
1000 710.7

For Oly/Pana:
1000 710.8

For Fuji:
1000 711.0

QR Code Technology

Scan the QR code for more product information

CAPTUR

Module - Timer

Captur Module - Timer | 1000 708.3

Wireless: Requires Captur (Sold Separately)

Wireless Timer Remote

Receiver

WIRELESS
UP TO 100m
2.4GHz

Timer

- Wireless Remote Shutter Release and Timer Remote
- Timer Remote ideal for time-lapse photography. Whether it's a blooming flower, changing landscapes, the options are endless
- Fully programmable timed sequence of delay timer, interval timer, exposure count and exposure length setting
- Wireless* Remote Shutter Release with auto-focus, single & continuous shooting and bulb mode lock option.
- Connect wirelessly to the camera using the ''Captur'' (Sold separately)
- DCM - Digital Channel Matching

Endless Possibilities

Time Lapse Photography
Landscapes, cloudscapes, slow growing plants & more come to life using time lapse photography. You can take multiple photographs at intervals over a long period of time & edit into a moving sequence. All of which is possible using the Module Timer.

Long Exposure
This type of photography can bring real life into your photographs by capturing moving objects with longer exposure times. Use the Module - Timer to create fantastic shots of starscapes, landscapes, seascapes & more.

QR Code Technology
Scan the QR code for more product information

hähnel
quality accessories

CAPTUR

Module - Pro

The Module - Pro has a built-in motion, light and sound sensor as well as a AUX socket to connect 3rd party sensors such as pressure plates. Also included is the Module - IR which can trigger the camera when a moving subject breaks the beam. Ideal for wildlife and sport's photography.

Module - Pro   1000 708.1

Built-in Sensors

Light
Capture sudden changes in light levels using the Module Pro. Ideal for lightening and fireworks. The built in light sensor can trigger your camera or flash when the light level goes above or below a certain level

Sound
This sensor of the Module Pro can trigger your camera or flash when it detects a sound. Capture glass shattering, a balloon popping & more.

Laser
The laser sensor of the Module Pro easily detects when something breaks the laser beam. Great for capturing water droplets, macro and wildlife shots.

Infrared
The built in infra-red sensor can be set up to trigger your camera when something breaks through the beam. Fantastic for wildlife and sports photography & even water droplets hitting the surface.

Wireless Universal Trigger Remote

- Captures Time Lapse Photography, High Speed Photography, Motion & Wildlife Photography
- Four built-in sensors (light, sound, Laser* & IR)
- Fully programmable timed sequences including delay, interval timer, exposure count & exposure length setting
- Shutter release button with autofocus, single & continuous shooting & bulb mode
- Connect wirelessly to camera with the use of the "Captur" (Sold separately)
- DCM - Digital Channel Matching

Laser pointer sold separately

Module - IR

Endless Possibilities

Time Lapse Photography
Landscapes, cloudscapes, slow growing plants & more come to life using time lapse photography. You can take multiple photographs at intervals over a long period of time & edit into a moving sequence. All of which is possible using the Module - Pro.

Long Exposure
This type of photography can bring real life into your photographs by capturing moving objects with longer exposure times. Use the Module - Pro to create fantastic shots of starscapes, landscapes, seascapes & more.

AUX
Auxiliary port allows you to connect 3rd party sensors such as pressure plates, Humidity & Temperature sensors

QR Code Technology

Scan the QR code for more product information

CAPTUR

New Cable Sets for CAPTUR

New Cable Sets for CAPTUR

If a consumer is interested in purchasing just the Captur Module Pro, they would need to purchase the branded Cable Set & connect the Module Pro direct to the camera.

For wireless connection, they would need to purchase the branded Cable Set, Pro Module & Receiver.

These cables are also compatible with the Giga T Pro II.

Product Name	Part No.	EAN Code
Cable Pack Canon	1000 714.0	5099113007148
Cable Pack Nikon	1000 714.1	5099113107145
Cable Pack Sony	1000 714.2	5099113207142
Cable Pack P/Oly	1000 714.3	5099113307149
Cable Fuji	1000 714.4	5099113407146

QR Code Technology

Scan the QR code for more product information

CAPTUR **For Canon** — PT No. 1000 710.0

CAPTUR **For Nikon** — PT No. 1000 710.1

CAPTUR **For Sony** — PT No. 1000 710.2

CAPTUR **For Olympus / Panasonic** — PT No. 1000 710.3

CAPTUR **For Fuji** — PT No. 1000 710.4

CAPTUR Module - Pro

compatible with
Canon, Nikon, Sony,
Olympus/Panasonic & Fuji
Captur Kits
(sold separately)

PT No. 1000 708.1

CAPTUR Module - Timer

compatible with
Canon, Nikon, Sony,
Olympus/Panasonic & Fuji
Captur Kits
(sold separately)

PT No. 1000 708.3

CAPTUR Receiver **For Canon**
available for
Canon Captur Kit
(sold separately)
PT No. 1000 710.5

CAPTUR Receiver **For Nikon**
available for
Nikon Captur Kit
(sold separately)
PT No. 1000 710.6

CAPTUR Receiver **For Sony**
available for
Sony Captur Kit
(sold separately)
PT No. 1000 710.7

CAPTUR Receiver **For Oly/Pana**
available for
Olu/Pana Captur Kit
(sold separately)
PT No. 1000 710.8

CAPTUR Receiver **For Fuji**
available for
Fuji Captur Kit
(sold separately)
PT No. 1000 711.0

Product	Part No.	Compatibility	Range	Wireless
Captur for Canon DSLR	1000 710.0	**Canon:** EOS 1200D/ EOS 1100D/ EOS 1000D/ EOS 650D/ EOS 600D/ EOS 550D/ EOS 500D/ EOS 450D/ EOS 400D/ EOS 350D/ EOS 300D/ EOS 100D/ EOS 70/ EOS 60D/ EOS 50D/ EOS 40D/ EOS 30D/ EOS 20D/ EOS 20DS/ EOS 10D/ EOS 7D/ EOS 6D/ EOS 5D/ EOS 5D Mark III/ EOS 5D Mark II / EOS 1D/ EOS 1DX/ EOS 1DC/ EOS 1DS Mark II/ EOS 1DS Mark III/ EOS 1DS Mark IV/ Rebel T1i/ Rebel T2i/ SX50HS/ G10/ G11/ G12/ G15/ G16/ SX50/ G5x / D5 / D500 / D5500 **Pentax:** K-5 II/ K-5 IIs/ K-5/ K-7/ K-10/ K-20/ K-50/ K-100/ K-200/ K-500 **Samsung:** GX10/ GX20	Up to 100m	√
Captur for Nikon DSLR	1000 710.1	P7700/ P7800/ D7200/ D7100/ D7000/ D5300/ D5200/ D5100/ D5000/ D3300/ D3100/ D3200/ D610/ D600/ D700/ D800/ D800E/ D300/ D300s/ D200/ D100 (when attached to Nikon MB-D100 battery grip)/ D3X/ D3S/ D4/ D2X/ D2XS/ D2H/ D2HS/ D1 / D1X/ D1H/ D80/ D70s/ D90/ Df/	Up to 100m	√
Captur for Sony DSLR	1000 710.2	A77/ A350/ A100/ A200/ A300/ A450/ A500 / A550/ A700/ A850/ A900/ A560/ A580/ A33/ A55/ A35 / A37/ A57/ A65/ A99/ A7s/ A58/ A77 II/ A3000/ A5000/ A6000/ HX400/ RX100II/ RX100III/ A7s Mk II/ RX100 IV / A7s Mk II / A7r Mk II	Up to 100m	√
Captur for Olympus/ Panasonic DSLR	1000 710.3	**Olympus:** Stylus 1/ E-620/ E-600/ E-550/ E-520/ E-510/ E-450/ E-420/ E-410/ E-400/ E-P5/ EP-1/ EP-2/ EP-3/ E-PL5/ E-PL2/ E-PM1/ E-PM2/ OM-D E-M10/ OM-D E-M5/ SP-590UZ/ SP-570UZ/ SP-565UZ/ SP-560UZ/ SP-550UZ/ SP-510UZ/ XZ-1 / XZ-2 / PEN-F / OM-D E-M10 Mk II **Panasonic:** FZ200/ FZ150/ FZ100/ FZ60/ FZ50/ FZ30/ FZ20 / G10/ G6/ G5/ G3/ G2/ G1 / GF1/ GH1/ GH2/ GH3/ GH4/ L10/ L1/ LC1/ DMC-GH4/ DMC-G7/ DMC-G70/ DMC-FZ300/ DMC-FZ330	Up to 100m	√
Captur for Fuji DSLR	1000 710.4	Fujifilm X-A1/ X-A2/ X-M1/ X-Q1/ X-Q2/ X-T1/ X-T10/ X30/ X100T/ X-E2/ X-S1/ X-E1/ Finepix S1/ HS20EXR/ HS22ER/ HS25EXR/ HS28EXR/ HS30EXR/ HS33EXR/ HS35EXR/ S100FS/ S200EXR/ S205EXR	Up to 100m	√
Captur Module - Pro	1000 708.1	Captur, Canon, Nikon, Sony & Olympus/Panasonic	Up to 100m	√
Captur Module - Timer	1000 708.3	Captur, Canon, Nikon, Sony & Olympus/Panasonic	Up to 100m	√
Accessory - Receiver For Canon DSLR	1000 710.5	Same compatibility as Captur Remote Control	Up to 100m	√
Accessory - Receiver For Nikon DSLR	1000 710.6	Same compatibility as Captur Remote Control	Up to 100m	√
Accessory - Receiver For Sony DSLR	1000 710.7	Same compatibility as Captur Remote Control	Up to 100m	√
Accessory - Receiver For Olympus/ Panas DSLR	1000 710.8	Same compatibility as Captur Remote Control	Up to 100m	√
Accessory - Receiver For Fuji DSLR	1000 711.0	Same compatibility as Captur Remote Control	Up to 100m	√